

4	3	2	1
spodní pl. ↓	↑ vrchní pl.	spodní pl. ↓	↑ vrchní pl.
AcI 9	AcI 6	AcI 5	AcI 5
NM	NM	NM	Mimo provoz
NMBIO	NMBIO	NMBIO	
TEMPNM	NMADD	NMADD	
NMADD	NM31MR	NM31MR	
NM31MR	NM_U	NM_U	
(MEŘO)	(MEŘO)	(MEŘO)	
AcI 8	AcI 11	AcI 2	AcI 1
NM	95ADD	NM	Mimo provoz
NMBIO	95CARR	NMBIO	
TEMPNM	BA95N	NMADD	
NMADD	OPTIMAL 95	NM31MR	
NM31MR	BA95_U	NM_U	
NM_U	ET85	(MEŘO)	
(MEŘO)	(ET)	MEŘO	
AcI 7		AcI 1	AcI 3
95ADD		MEŘO	95ADD
95CARR			95CARR
TEMP95			BASPEC
BA95N			BA95N
BA95NB			BA95NB
OPTIMAL 95			OPTIMAL 95
BA95_U			BA95_U
ET85			ET85
(ET)			(ET)
AcI 10		AcI 4	
95ADD		95ADD	
95CARR		95CARR	
TEMP95		BASPEC	
BA95N		BA95N	
BA95NB		BA95NB	
OPTIMAL 95		OPTIMAL 95	
BA95_U		BA95_U	
ET85		ET85	
(ET)		(ET)	
4	3	2	1

sklad Třemošná

celový stav plnicích lávek